



Features:

- Each Motion Sensor has its own built-in WIFI module to communicate directly with a standard Router or Extender
- Notifications are sent to your Smartphone or Tablet when movement is detected
- Notifications are silent or accompanied by a Chime or Alarm Tone
- Local Alert Option upon Sensor activation - Sounder built into the WiFi Socket or flashing WiFi Light Bulb
- Additional Low Battery and Loss of Signal Alerts sent
- Simply download the powerful free Android or iOS APP and pair the Device to a Router or Extender
- APP records last 30 activations with Time and Date stamp
- Super Low Power Consumption
- Up to 100 individual Devices can be registered and seen in the APP & shared with other Smart Phones
- Schedule up to 4 periods per day when the Sensor is automatically turned OFF
- Personalize your Sensor in the APP by adding a description and a photo
- Free life-time Cloud Service
- Sensor can send an Instant Alert or is programmable to look for either 5, 15 or 30 minutes of no motion before sending a subsequent Alert



Other NetzHome Sensors available include:



WiFi Socket



Shock Sensor



Door/Window Contact



Floating Water Temperature Sensor



Water Leakage/Level Sensor



Panic Button



WiFi Light Bulb



Universal NO/NC Device



Temperature Sensor

Keystone Electronics Limited

The Colmore Building, 20 Colmore Circus
Queensway, Birmingham B4 6AT

Tel: +44 (0) 121 2624214 Email: sales@keystone-electronics.co.uk
Web Site: www.keystone-electronics.co.uk